1 Maste-Skript TSX\_3 about:srcdoc

```
In [ ]: # packages
        import os
        from osgeo import gdal, ogr, gdal_array # I/O image data
        import joblib
        import numpy as np # math and array handling
        import matplotlib.pyplot as plt # plot figures
        from matplotlib.colors import ListedColormap # to import certain defined co
        lor palettes for plotting your results
        from sklearn.ensemble import RandomForestClassifier # classifier
        import pandas as pd # handling large data as table sheets
        from sklearn.metrics import classification_report, accuracy_score,confusion
        _matrix # calculating measures for accuracy assessment
        from sklearn.neighbors import KNeighborsClassifier
        from skimage import exposure # for adjustment of rasterstack (histogram eq
        ualization, etc)
        # Tell GDAL to throw Python exceptions, and register all drivers
        gdal.UseExceptions()
        gdal.AllRegister()
In [ ]: | # path where my data is located
        folder_src = r"C:\Users\rwolff\Documents\Lac Bam SSD\Test\Neuer Ordner\TDX_
        folder_src_shape = r"C:\Users\rwolff\Documents\Lac Bam SSD\Shapefiles class
        ification angepasste Klassen"
        # path where I want to save my results
        folder_results = r"E:\CSV_27 Aufnahmen\TSX"
In [ ]: # how many cores should be used?
        n_{cores} = -1
        # -1 -> all available cores
```

```
In [ ]: #import os
        directory = folder_src
        directory_shapes = folder_src_shape
        iterator = 0
        for filename_tif, filename_shape in zip(os.listdir(directory),[f for f in o
        s.listdir(directory_shapes) if f.endswith('.shp')]):
          file = os.path.join(directory, filename_tif)
          if os.path.isfile(file):
            print(file)
            s2_stack=file
            print(s2_stack)
            filename = filename_tif
            # Load image data
            #In this script we are Using gdal.open() instead of rio.open()
            img_ds = gdal.Open(s2_stack, gdal.GA_ReadOnly)
            img = np.zeros((img_ds.RasterYSize, img_ds.RasterXSize, img_ds.RasterCo
        unt),
                        gdal_array.GDALTypeCodeToNumericTypeCode(img_ds.GetRasterBan
        d(1).DataType))
            for b in range (img.shape[2]):
                 img[:, :, b] = img_ds.GetRasterBand(b + 1).ReadAsArray()
            print("Raster format is:", gdal_array.GDALTypeCodeToNumericTypeCode(img
        _ds.GetRasterBand(1).DataType))
        # store the variables above in a more meaningful way. You will use these va
        riables later.
            row = img_ds.RasterYSize
            col = img_ds.RasterXSize
            band_number = img_ds.RasterCount
            print("Raster number of rows: {}".format(row))
            print("Raster number of columns: {}".format(col))
            print("Raster number of bands: {}".format(band_number))
        # Take our full image and reshape into long 2d array (nrow * ncol, nband) f
        or classification
            #new_shape = (img.shape[0] * img.shape[1], img.shape[2])
            #img_as_array = img[:, :, : int(img.shape[2])].reshape(new_shape)
            #print('Reshaped from {o} to {n}'.format(o=img.shape, n=img_as_array.sh
        ape))
            training = folder_src_shape + "\\" + filename_shape
        # what is the numerical attribute of your classes in the shapefile?
            attribute = 'id'
        # load training data and show all shapefile attributes
            print(training)
            shape_dataset = ogr.Open(training)
             shape_layer = shape_dataset.GetLayer()
        # extract the names of all attributes (fieldnames) in the shape file
```

```
attributes = [] # empty list where the attributes will be saved
    ldefn = shape_layer.GetLayerDefn() # encapsulates the attribute schema
of the features of the layer
   for n in range(ldefn.GetFieldCount()):
        fdefn = ldefn.GetFieldDefn(n)
        attributes.append(fdefn.name)
# print the attributes
   print('Available attributes in the shapefile are: {}'.format(attribute
s))
# copy the structure of your Sentinel2 image to pass this information to th
e new rasterized polygons
    mem_drv = gdal.GetDriverByName('MEM')
    mem_raster = mem_drv.Create('',img_ds.RasterXSize,img_ds.RasterYSize,1,
gdal.GDT Byte)
   mem_raster.SetProjection(img_ds.GetProjection())
    mem_raster.SetGeoTransform(img_ds.GetGeoTransform())
   mem_band = mem_raster.GetRasterBand(1)
   mem_band.Fill(0)
    mem_band.SetNoDataValue(0)
   att_ = 'ATTRIBUTE='+attribute
# rasterize your polygons
    err = gdal.RasterizeLayer(mem_raster, [1], shape_layer, None, None,
[1], [att_,"ALL_TOUCHED=TRUE"])
    assert err == gdal.CE_None
    roi = mem_raster.ReadAsArray()
# Number of training pixels:
    n_samples = (roi > 0).sum()
    print('{n} training samples'.format(n=n_samples))
# What are our classification labels?
    labels = np.unique(roi[roi > 0])
    print('training data include {n} classes: {classes}'.format(n=labels.si
ze, classes=labels))
    # Subset the image dataset with the training image = X
   # Mask the classes on the training dataset = y
    # These will have n_samples rows
   X = img[roi > 0, :]
   y = roi[roi > 0]
    if iterator == 0:
       X_{concat} = X.copy()
        y_concat = y.copy()
    else:
        X_concat1 = X_concat.copy()
        y_concat1 = y_concat.copy()
        X_concat = np.concatenate((X_concat1, X), axis=0)
        y_concat = np.concatenate((y_concat1, y), axis=0)
```

```
iterator+=1
In [ ]: klassen, Anzahl=np.unique(y_concat , return_index=False, return_inverse=False)
        e, return_counts=True, axis=None)
        print(Anzahl)
        print(klassen)
In [ ]: | ## SAFE X concat to CSV
        array_X = X_concat
        df = pd.DataFrame(array_X)
        display(df) #Alternative zu print()
        #1. Schritt: CSV-File wird geschrieben
        output_name = 'X_concat TDX_3test.csv'
        output_folder = r"E:\CSV Data\TSX"
        output_data = os.path.join(output_folder, output_name)
        if os.path.isfile(output_data): #checks, if file already exists
             print ("\nFile already exists in {}! Image was not saved!".format(outpu
        t_data))
        else:
            df.to_csv(output_data)
            print ("\nCsv-file was successfully saved in {}!".format(output_data))
        ## SAFE y_concat to CSV
        array_y = y_concat
        df = pd.DataFrame(array_y)
        display(df) #Alternative zu print()
        #1. Schritt: CSV-File wird geschrieben
        output_name = 'y_concat TDX_3test.csv'
        output_folder = r"E:\CSV Data\TSX"
        output_data = os.path.join(output_folder, output_name)
        if os.path.isfile(output_data): #checks, if file already exists
            print ("\nFile already exists in {}! Image was not saved!".format(outpu
        t_data))
        else:
            df.to csv(output data)
            print ("\nCsv-file was successfully saved in {}!".format(output_data))
In [ ]: klassen,Anzahl=np.unique(array_y, return_index=False, return_inverse=False,
        return counts=True, axis=None)
        print(Anzahl)
        print(klassen)
In [ ]:
```